

BASEGRILL 9/8" & 5/8" STAINLESS STEEL GRID HARDWARE INSTRUCTIONS



1. Select areas on the panels to install hold-down clips (pre-assembled hardware) Typically at the four corners will suffice but be sure that the hold downs will not interfere with the existing frame piece. For cosmetic reason locate the clips on each panel in the same areas.



2. Carefully place the panels in the recess. Adjust fit as needed and place exactly for final location



3. Dip on end of 1/8" allen wrench in puddle of pen ink or marking paint.

BASEGRILL 9/8" & 5/8" STAINLESS STEEL GRID HARDWARE INSTRUCTIONS



4. Carefully feed wrench through surface wires and mark cement floor at center keyhold of clip. These will be the location spots to install lead anchors



5. Carefully remove panels from the recess. Keep in mind that these panels are not interchangeable. They will need to be re-installed in identical locations after the anchors are placed



6. At the marked location on the floor, drill with a 3/8" concrete drill to the proper depth to fit the anchor. The holes must be free of dust and debris and oil prior to installing anchors



7. Mix epoxy in separate tray and place adequate amount in each hole just prior to installing anchor. Preferred epoxy is Red Head Epon A7 Fast Curling Acrylic.

BASEGRILL 9/8" & 5/8" STAINLESS STEEL GRID HARDWARE INSTRUCTIONS



8. Install anchor making sure the threaded part is upright and straight and free of excess epoxy. After anchors have set in place and cured, carefully re-install panels in original positions



9. Feed the 1/8" allen wrench through surface wires and tighten cap screws to hold panels in position



10. The BaseGrill is now Secured using lock downs.